


# REPLACEMENT PARTS - SCS VAN UNITS

Model HC740




**Replacement Parts:**

064-00010 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 041-00056 Evaporator Coil
- 034-00026 Expansion Valve

Model HC740




**Replacement Parts:**

088-00129 Assembly Including:

- 060-00153 Blower Housing
- 030-00086 Blower Motor
- 062-00183 Blower Wheel
- 041-00056 Evaporator Coil
- 034-00026 Expansion Valve

Model HC751




**Replacement Parts:**

088-00128 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 041-00082 Evaporator Coil
- 034-00026 Expansion Valve

Model HC753




**Replacement Parts:**

088-00094 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 034-00026 Expansion Valve

Model HC767




**Replacement Parts:**

090-00160 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 034-00026 Expansion Valve

Model HC791




**Replacement Parts:**

090-00161 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 041-00053 Evaporator Coil
- 034-00026 Expansion Valve

# REPLACEMENT PARTS - SCS VAN UNITS


Model 800



**Replacement Parts:**  
088-00180 Assembly Including:

- 060-00153 Blower Housing
- 030-00086 Blower Motor
- 062-00227 Blower Wheel
- 041-00054 Evaporator Coil
- 034-00026 Expansion Valve
- 062-000217 Motor Mount
- 031-00001 Relay


Model 951



**Replacement Parts:**  
090-00164 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 041-00057 Evaporator Coil
- 034-00026 Expansion Valve


Model 957



**Replacement Parts:**  
086-00217 Assembly Including:

- 062-00245 Blower Housing
- 030-00028 Blower Motor
- 062-00183 Blower Wheel
- 034-00026 Expansion Valve

Model FMHC



**Replacement Parts:**  
088-00097 Assembly Including:

- 062-00008 Blower Housing
- 030-00001 Blower Motor
- 062-00002 Blower Wheel
- 034-00046 Expansion Valve
- 051-00034 Motor Vent Tube
- 035-00012 Resistor

090-00368

ILLUSTRATION NOT AVAILABLE

**Replacement Parts:**  
088-00198 Assembly Including:

- 062-00008 Blower Housing
- 030-00001 Blower Motor
- 062-00002 Blower Wheel
- 041-00145 Evaporator Coil
- 042-00041 Heater Coil
- 034-00026 Expansion Valve
- 051-00034 Motor Vent Tube
- 031-00001 Relay
- 035-00037 Resistor

090-00386

ILLUSTRATION NOT AVAILABLE

**Replacement Parts:**  
088-00226 Assembly Including:

- 062-00008 Blower Housing
- 030-00001 Blower Motor
- 062-00002 Blower Wheel
- 041-00145 Evaporator Coil
- 042-00041 Heater Coil
- 034-00026 Expansion Valve
- 051-00034 Motor Vent Tube
- 031-00001 Relay
- 035-00037 Resistor

# REPLACEMENT PARTS - SCS VAN UNITS


090-00397  
1999—2000 Astro Van Unit

ILLUSTRATION NOT AVAILABLE

**Replacement Parts:**  
088-00233 Assembly Including:

083-00217 Blower Assembly  
041-00154 Evaporator Coil  
034-00026 Expansion Valve  
035-00037 Resistor

Model HC720



**Replacement Parts:**  
086-00144 Assembly Including:

062-00191 Blower Housing  
030-00054 Blower Motor  
062-00252 Blower Wheel  
041-00089 Evaporator Coil  
034-00026 Expansion Valve  
035-00011 Resistor


090-00400 Chevy & GMC  
090-00401 Ford  
090-00402 Dodge

ILLUSTRATION NOT AVAILABLE

**Replacement Parts:**  
088-00239 Assembly Including:

062-00113 Blower Housing  
030-00004 Blower Motor  
062-00010 Blower Wheel  
041-00155 Evaporator Coil  
042-00041 Heater Coil  
034-00026 Expansion Valve  
035-00037 Resistor

Model HC722



**Replacement Parts:**  
086-00216 Assembly Including:

086-00100 Blower Assembly  
034-00026 Expansion Valve  
035-00011 Resistor